6200
SERIES

Art. 6296

IP videophone



videokit by VIDEX

IP

ENG Quick guide

VIDEX®

THE POWER TO SECURE

66251116 - V 1.0 - 31/03/18

Overview and button operations

OVERVIEW



ANSWERING A CALL



To answer a call simply pick up the handset.

OPEN THE DOOR



Press the button to open the door.

Button operations

TO ENABLE/DISABLE PRIVACY SERVICE



1



Press button to activate or deactivate the privacy service. The LED will illuminate when the service is active.

TIP



During an incoming call, with the service is enabled, the device does not emit any acoustic signal.

TIP



To set privacy duration, please see **"Set Privacy duration" on page 10.**

REJECT A CALL



1



Press button to reject a call.

SERVICE BUTTON



1



Press the **S** button to activate the favourite service (if set). **By default this button is disabled.**

TIP

To enable this button for services to activate in stand-by mode or during a conversation, please contact the installer.

RING VOLUME ADJUSTMENT



1



Move the switch, under the symbol, to the left for a lower volume, to the center for a medium volume and to the right for a higher volume.

BRIGHTNESS DISPLAY ADJUSTMENT



1



Turn the roller under the symbol to the left to reduce and to the right to increase the brightness.

Button operations

CAMERA RECALL TO FAVORITE DOOR PANEL

1



Press the ○ button.

WARNING!



If the "Panel address book" is empty a warning is shown.
To add recall please contact the installer.

2



Pick up the handset.
The display shows the video from the door panel.

3



To screen shot press ○ momentarily.

4

To enable the speech and start a conversation press and keep pressed the ○ button until the display shows the symbol.

5



To open the door press the button.

6



To switch to another video source (if enabled), press and keep pressed the button until the display shows the camera switch notice.

6



To close the connection hang up the handset.

Button operations

INTERCOMMUNICATING WITH FAVORITE INDOOR STATION

1



Press the button.

WARNING!



If the "Intercom address book" is empty a warning is shown.
To add intercommunication please contact the installer.

2



Pick up the handset and wait for the other party to answer.



When the preferred videophone answers you can talk with them.
The display shows the symbol.



To close the connection hang up the handset.

Main menu touch screen operations

ENTER MAIN MENU

During stand-by

1



Tap the black screen.

2



Main menu will appear.

ACTIVATION OF SERVICES

1

Tap S

WARNING!



If the "Remote outputs list" a warning will be shown.
Contact the installer to add services.

2



Select the service to activate then tap ✓ to activate it.

3



A notice will appear to confirm the activation.

4

Active another service or tap ↩ to go back to the main menu.

Main menu touch screen operations

CAMERA RECALL A DOOR PANEL FROM THE PANEL ADDRESS BOOK

1



Tap

WARNING!



If the "Panel address book" is empty a warning is shown.
Contact the installer to add camera recall.

2



Select the door panel to connect to then tap ✓ to open the communication.

3



Pick up the handset.
The display shows the video coming from the door panel.

4



To take a screen shot press ○ button momentarily.

5



To enable the speech and start a conversation press and keep pressed the ○ button until the display shows the 🔊 symbol.

6

To open the door press the 🔑 button.

7



To switch to another video source (if enabled), press and keep pressed the ✂ button until the display shows the camera switch notice.

8



To close the connection hang up the handset.

Main menu touch screen operations

INTERCOMMUNICATING WITH AN INDOOR STATION FROM ADDRESS BOOK

1

Tap

WARNING!



If the "Intercom address book" is empty a warning is shown. Contact the installer to add intercommunication.

2



Select the indoor station to call then tap to open the communication.

3



Pick up the handset and wait for the other party to answer.

4



When the called videophone answers you can talk with them.
The display shows the symbol.

5



To close the connection hang up the handset.

Main menu touch screen operations

VIEW THE EVENT LOG

1



Tap

2



Tap the event you want to inspect:

Red: missed call

Green: incomming call answered

Blue: out going call

3



To see a screen shot, keep pressed

4



To start a camera recall, tap an event with icon, then tap

5



To start an intercommunicating call, tap an event with icon, then tap

6

Tap to go back to main menu.

ACCESS TO SETTINGS MENU

1



Tap to enter the settings menu.

Settings menu - Programmable settings

ENTER AND NAVIGATE SETTINGS MENU

1



From main menu tap ⚙

2



For more settings tap ⇩
To go back to main menu tap ↩

3



To go make to previous page tap ⇧
To go back to main main menu tap ↩

TIP



If the screen is black, tap it to see main menu then tap ⚙ to open settings.

SET PRIVACY DURATION

1



Tap 🔕
The current value is shown.

2



Swipe among the values to select the required then tap ✓ to confirm.

3



A notice will inform that the value is saved. Tap ↩ to go back.

Settings menu - Programmable settings

SET MELODY

1



Tap 𝄞
The current melody is shown.

2



Tap on a melody to listen to it then tap ✓ to confirm the selected melody.

3



A notice will inform that the value is saved.
Tap ↩ to go back.

SET THE NUMBERS OF THE RINGS

1



Tap ♫
The current value is shown.

2



Swipe among the values to select the required then tap ✓ to confirm.

3



A notice will inform that the value is saved.
Tap ↩ to go back.

SET DATE & TIME

1



Tap
The current date & time are shown.

2



Use the buttons to adjust the date & time required then tap ✓ to confirm.

3



A notice will inform that the values are saved.
Tap ↩ to go back.

Settings menu - Adjustable settings

ADJUST OUTDOOR STATION SPEECH QUALITY

1



Tap
Enter the default password **9876**.

2



Select the door panel to connect to then tap ✓ to open the communication.

3



Adjust the speech using the + and – buttons.

4



Tap ✓ to confirm.

5



A notice will inform that the adjustment is saved.
Tap ↩ to go back.

ADJUST OUTDOOR STATION VIDEO QUALITY

1



Tap
Enter the default password **9876**.

2



Select the door panel to connect then tap ✓ to open the communication.

3



Adjust the video using the + and – buttons.

4



Tap **SAVE** to confirm.

5



A notice will inform that the adjustment is saved.
Tap **EXIT** to go back.

Settings menu - Adjustable settings

BINDING CODE

1



Tap
The screen will show the **"BINDING CODE"** QR code and text format.

2



Open the Videx Cloudnected app on your smartphone and tap on the + symbol in the top right corner.

3

Focus on the QR code or enter the text code.

4



After a while, if the binding is successful, the main screen of the app will list the installation to which the videophone is connected. Now the app is ready to use.

TIP



Get Videx Cloudnected on Google Play store.
Available for Android devices.
IOS version isn't available at the moment.

GET DEVICE INFO



Tap (i) to get device info.
Press ↩ to go back.

Note

Note

Manufacturer
Fabbricante
Fabricant
Fabricante
Fabrikant

THE POWER TO SECURE

Cert. N. IT05/1217

made in ITALY

VIDEX ELECTRONICS S.P.A.
Via del Lavoro, 1
63846 Monte Giberto (FM) Italy
Tel (+39) 0734 631669 - Fax (+39) 0734 632475
www.videx.it - info@videx.it

Customer support
Supporto clienti
Supports clients
Atención al cliente
Klantendienst

VIDEX ELECTRONICS S.P.A.
www.videx.it - technical@videx.it
Tel: +39 0734-631669
Fax: +39 0734-632475

UK Customers only:
VIDEX SECURITY LTD
www.videxuk.com
Tech Line: 0191 224 3174
Fax: 0191 224 1559

66251116

CE

The product is CE marked demonstrating its conformity and is for distribution within all member states of the EU with no restrictions. This product follows the provisions of the European Directives 2014/30/EU (EMC); 2014/35/EU (LVD); 2011/65/EU (RoHS): CE marking 93/68/EEC.

Le produit est marqué CE à preuve de sa conformité et peut être distribué librement à l'intérieur des pays membres de l'union européenne EU.
Ce produit est conforme aux directives européennes 2014/30/EU (EMC) ; 2014/35/EU (LVD) ; 2011/65/EU (RoHS): marquage CE 93/68/EEC.

Het product heeft de CE-markering om de conformiteit ervan aan te tonen en is bestemd voor distributie binnen de lidstaten van de EU zonder beperkingen. Dit product volgt de bepalingen van de Europese Richtlijnen 2014/30/EU (EMC); 2014/35/EU (LVD); 2011/65/EU (RoHS): CE-markering 93/68/EEG.

Il prodotto è marchiato CE a dimostrazione della sua conformità e può essere distribuito liberamente all'interno dei paesi membri dell'Unione Europea UE. Questo prodotto è conforme alle direttive Europee: 2014/30/UE (EMC); 2014/35/UE (LVD); 2011/65/UE (RoHS): marcatura CE 93/68/EEC.

El producto lleva la marca CE que demuestra su conformidad y puede ser distribuido en todos los estados miembros de la unión europea UE.
Este producto cumple con las Directivas Europeas 2014/30/EU (EMC); 2014/35/EU (LVD); 2011/65/EU (RoHS): marca CE 93/68/EEC.