

ART. 3102/G

3000 Series full base "4+1" audiophone incorporating an AC buzzer call input, an adjustable electronic call tone input, "door open" push button, spare service button and "hold open" switch.

For use on traditional "4+1" audio systems that require an AC buzzer call or an electronic call tone including the following audio kits: traditional VR audio systems, 4K series, 8K series, VR4K series and VR120DK series kits.

Call tone adjustments: 3 level (low, medium and high) call tone switch.


Hold Open override: 2 position "hold open" switch (ON = switch contacts closed / OFF = switch contacts open).





3102/G 3000 Series Audiophone QUICK GUIDE














conversation with the caller can begin.





To end the call replace the handset back on the cradle.













To end the call replace the handset back on the cradle.


CALL TONE VOLUME ADJUSTMENT (CALL TONE ONLY)






Move the volume switch to the lower position to set the call tone volume to low, to the middle position to set the call tone volume to medium and to the upper position to set the call tone volume to high.


OPERATING THE HOLD OPEN SWITCH





To engage the hold open contacts (i.e. contacts closed), move the switch to the ON position. To disengage the hold open contacts (i.e. contacts open), move the switch to the OFF position.

SPARE SERVICE BUTTON





Press the spare service button to activate a secondary function (if this was set up during the installation).

TECHNICAL ADVICE



For further technical advice and assistance on the installation of this product please contact Videx technical on tel: 0191 224 3174.

For any sales advice and assistance please contact Videx sales on tel: 0191 238 8324.

To download a copy of this quick guide visit the Videx website: www.videxuk.com